

FIRST AID

Eyes: Rinse immediately with clean water for 15–20 minutes. Remove contact lenses if present and easy to do. Seek medical attention.

• *Skin: Remove contaminated clothing. Wash thoroughly with plenty of water.*

• *Inhalation: Move to fresh air and keep at rest.*

• *If swallowed: Rinse mouth. Do NOT induce vomiting. Drink a glass of water or milk. Seek immediate medical attention.*

• *If symptoms persist, seek medical attention.*

PRODUCT DESCRIPTION

Medipro Shield is a chlorine-based disinfectant granules intended for institutional surface and floor disinfection in hospital and healthcare premises.

Free-flowing chlorine granules for institutional surface disinfection.

INTENDED APPLICATIONS

Floor disinfection
Toilets and drainage areas
Blood and body-fluid spill areas
High-risk environmental surfaces

MANUFACTURED BY

JAL AQUA INTERNATIONAL LIMITED
Plot No. 620, Road No. 6, Beside PETL,
GIDC, Panoli, Ankleshwar, Gujarat – 394115

MARKETED BY

SHRI RAM EXPORTS
Ug, 14 To 22, Sargam Complex, Opp. Bhulka Bhavan,
Surat-395009

Mail :- tarang@jalaquainternational.com

Phone :- +91 96624 81009

INGREDIENTS

Active Ingredient: Chlorine-based disinfecting compound

in Active chlorine: ≥68% w/w

Other Ingredients: Balance

WARNING

KEEP OUT OF REACH OF CHILDREN

Read all the precautionary statement on label and first aid statements before use.



MEDIPRO SHIELD

INSTITUTIONAL SURFACE
DISINFECTANT
GRANULES



FLOOR



TOILET



HOSPITAL / CLINICS



HOTELS

Net Wt **1** Kg

DIRECTION FOR USE

Standard surface disinfection dilution. Dissolve Medipro Shield granules in clean water at the rate shown below. Stir until fully dissolved before use.

Application	Dose	Contact time
Routine floors & environmental surfaces	7.5 g per 10 L water	5 minutes
High-risk / high-touch surfaces	15 g per 10 L water	5–10 minutes
Blood & body-fluid spills	75 g per 10 L water	10 minutes

- Apply the prepared solution evenly to the surface and keep wet for the full contact time.
- For spills, cover the area with solution, leave for 10 minutes, then remove and clean.
- Prepare fresh solution before each use. Use within 24 hours; discard any unused solution.
- A measuring scoop is recommended for accurate dosing.

STORAGE CONDITIONS

Do not contaminate food or feed by storage, disposal, or cleaning of equipment.

- Store in a cool, dry, well-ventilated area
- Do not reuse or refill container
- Rinse empty container thoroughly before disposal
- Do not pour unused product into drains

SAFETY & HANDLING

- Wear gloves and mask during handling
- Avoid contact with skin and eyes
- Do not mix with acids, ammonia, or other cleaning chemicals
- Keep container tightly closed when not in use
- Contact with acids releases toxic chlorine gas.

MRP :

Batch No:

Mfg Date:

Expiry Date:

USE LIMITATION

For institutional and surface disinfection use only. Not intended for direct human application, patient care, or medical device disinfection.